

MEITRACK MVT100/MVT340/MVT380 GPRS Protocol

Applicable Model: MVT100/MVT340/MVT380

Change History

File Name	MEITRACK MVT100/MVT340/MVT380 GPRS Protocol	Created By	Kyle Lv
Project	MVT100/MVT340/MVT380	Creation Date Update Date	2017-01-20
Subproject	GPRS Protocol	Total Pages	23
Version	V1.0	Confidential	Internal Documentation

Contents

1 Command Format.....	5 -
1.1 GPRS Command Format	5 -
1.2 Tracker Command Format	5 -
1.3 Event Code.....	8 -
2 Command List.....	9 -
3 Command Details	10 -
3.1 Real-Time Location Query – A10	10 -
3.2 Setting a Heartbeat Packet Reporting Interval – A11.....	10 -
3.3 Tracking by Time Interval – A12	10 -
3.4 Setting the Cornering Report Function – A13	11 -
3.5 Tracking by Distance – A14	11 -
3.6 Setting the Parking Scheduled Tracking Function – A15	12 -
3.7 Enabling the Parking Scheduled Tracking Function – A16.....	12 -
3.8 Setting GPRS Parameters – A21	12 -
3.9 Setting the DNS Server IP Address – A22.....	13 -
3.10 Setting the Standby GPRS Server – A23.....	13 -
3.11 Reading All Authorized Phone Numbers – A70.....	14 -
3.12 Setting Authorized Phone Numbers – A71	14 -
3.13 Setting Listen-in Phone Numbers – A72	14 -
3.14 Setting the Smart Sleep Mode – A73.....	15 -
3.15 Automatic Event Report – AAA.....	15 -
3.16 Deleting a GPRS Event in the Buffer – AFF	15 -
3.17 Setting a Geo-Fence – B05.....	16 -
3.18 Deleting a Geo-Fence – B06.....	16 -
3.19 Setting the Speeding Alarm Function – B07	17 -
3.20 Setting the Towing Alarm Function – B08.....	17 -
3.21 Setting the Anti-Theft Function – B21	17 -
3.22 Turning off the LED Indicator – B31	18 -
3.23 Setting a Log Interval – B34	18 -
3.24 Setting the SMS Time Zone – B35.....	18 -
3.25 Setting the GPRS Time Zone – B36	19 -
3.26 Checking the Engine First to Determine Tracker Running Status – B60	19 -
3.27 Setting SMS Event Characters – B91	19 -
3.28 Setting Event Authorization – B99	20 -
3.29 Controlling Output Status – C01	20 -
3.30 Notifying the Tracker of Sending an SMS – C02	21 -
3.31 Setting a GPRS Event Transmission Mode – C03.....	21 -
3.32 Reading Device's Firmware Version and SN – E91	22 -
3.33 Restarting the GSM Module – F01.....	22 -
3.34 Restarting the GPS Module – F02	22 -
3.35 Setting the Mileage and Run Time – F08	22 -
3.36 Deleting SMS/GPRS Cache Data – F09	23 -

3.37 Restoring Initial Settings – F11.....- 23 -

1 Command Format

1.1 GPRS Command Format

- GPRS command sent from the server to the tracker:
`@@<Data identifier><Data length>,<IMEI>,<Command type>,<Command><*Checksum>\r\n`
- GPRS command sent from the tracker to the server:
`$$<Data identifier><Data length>,<IMEI>,<Command type>,<Command><*Checksum>\r\n`

1.2 Tracker Command Format

`$$<Data identifier><Data length>,<IMEI>,<Command type>,<Event code>,<(-)Latitude>,<(-)Longitude>,<Date and time>,<Positioning status>,<Number of satellites>,<GSM signal strength>,<Speed>,<Direction>,<Horizontal dilution of precision (HDOP)>,<Altitude>,<Mileage>,<Run time>,<Base station info>,<l/O port status>,<Analog input value>,<Geo-fence number><*Checksum>\r\n`

Note:

- A comma (,) is used to separate data characters. The character type is the American Standard Code for Information Interchange (ASCII). (Hexadecimal is represented as 0x2C.)
- Symbols "<" and ">" will not be present in actual data, only for documentation purpose only.
- All multi-byte data complies with the following rule: High bytes are prior to low bytes.
- The size of a GPRS data packet is about 160 bytes.

Descriptions about GPRS packets from the tracker are as follows:

Parameter	Description	Example
@@	Indicates the GPRS data packet header sent from the server to the tracker. The header type is ASCII. (Hexadecimal is represented as 0x40.)	@@
\$\$	Indicates the GPRS data packet header sent from the tracker to the server. The header type is ASCII. (Hexadecimal is represented as 0x24.)	\$\$
Data identifier	Contains 1 byte. The type is the ASCII, and its value ranges from 0x41 to 0x7A.	Q
Data length	Indicates the length of characters from the first comma (,) to \r\n. Decimal. Example: <code>\$\$<Data identifier><Data length>,<IMEI>,<Command type>,<Command><*Checksum>\r\n</code>	25
IMEI	Indicates the tracker IMEI number. The number type is ASCII. It has 15 digits generally.	353358017784062
Command type	Hexadecimal For details, see chapter 2 and chapter 3.	AAA
Event code	Decimal For details, see section 1.3 "Event Code."	1
Latitude (-)yy.dddddd	Unit: degree Decimal When a minus (-) exists, the tracker is in the southern hemisphere.	22.756325 (indicates 22.756325°N) -23.256438 (indicates

	When no minus (-) exists, the tracker is in the northern hemisphere. yy indicates the degree. dddddd indicates the decimal part.	23.256438°S)
Longitude (-)xxx.dxxxxx	Unit: degree Decimal When a minus (-) exists, the tracker is in the western hemisphere. When no minus (-) exists, the tracker is in the eastern hemisphere. xxx indicates the degree. dddddd indicates the decimal part.	114.752146 (indicates 114.752146°E) -114.821453 (indicates 114.821453°W)
Date and time yyymmddHHMMSS	yy indicates year. mm indicates month. dd indicates day. HH indicates hour. MM indicates minute. SS indicates second. Decimal	091221102631 Indicates 21 December 2009, 10:26:31 am.
Positioning status	Indicates the GPS signal status. A = Valid V = Invalid	A The GPS is valid.
Number of satellites	Indicates the number of received GPS satellites. Decimal	5 Five GPS satellites are received.
GSM signal strength	Value: 0–31 Decimal	12 The signal strength is 12.
Speed	Unit: km/h Decimal	58 The speed is 58 km/h.
Direction	Indicates the driving direction. The unit is degree. When the value is 0 , the direction is north. The value ranges from 0 to 359. Decimal	45: indicates that the location is at northeast. 90: indicates that the location is at east.
HDOP	The value ranges from 0.5 to 99.9. The smaller the value is, the more the accuracy is. Decimal When the accuracy value is 0 , the signal is invalid. 0.5–1: Perfect 2–3: Wonderful 4–6: Good 7–8: Medium 9–20: Below average 21–99.9: Poor	5 The HDOP is 5.
Altitude	Unit: meter Decimal	118
Mileage	Unit: meter	564870

	<p>Decimal</p> <p>Indicates the total mileage. The maximum value is 4294967295. If the value exceeds the maximum value, it will be automatically cleared.</p>	
Run time	<p>Unit: second</p> <p>Decimal</p> <p>Indicates the total time. The maximum value is 4294967295. If the value exceeds the maximum value, it will be automatically cleared.</p>	2546321
Base station info	<p>The base station information includes: MCC MNC LAC CI</p> <p>The MCC and MNC are decimal, while the LAC and CI are hexadecimal.</p> <p>Note: Base station information in an SMS is empty.</p>	460 0 E166 A08B
I/O port status	<p>Hexadecimal</p> <p>Status values of eight input ports and eight output ports: Bit0 to Bit7 corresponds to status of output ports 1 to 8. Bit8 to Bit15 corresponds to status of input ports 1 to 8.</p>	0421 (hexadecimal) = 0000 0100 0010 0001
Analog input value	<p>Separated by " ".</p> <p>Hexadecimal</p> <p>AD1 AD2 AD3 Battery analog External power analog</p> <p>Note: Analog input values in an SMS report are empty.</p> <p>Voltage formula of analog AD (AD1, AD2, and AD3): MVT340/MVT380: $(AD \times 6)/1024$ MVT100: $(AD \times 3.3 \times 2)/4096$</p> <p>Voltage formula of battery analog (AD4): MVT340/MVT380: $(AD4 \times 3 \times 2)/1024$ MVT100: $(AD4 \times 3.3 \times 2)/4096$</p> <p>Voltage formula of external power supply (AD5): MVT340/MVT380: $(AD5 \times 3 \times 16)/1024$ MVT100: $(AD5 \times 3.3 \times 16)/4096$</p>	123 456 235 1456 222 (Hexadecimal)
Geo-fence number	<p>32-bit unsigned</p> <p>Only available by GPRS event code 20 or 21.</p>	02 00 00 00 (indicates geo-fence 2)
*	<p>Separates commands from checksums.</p> <p>1 byte and ASCII (Hexadecimal is represented as 0x2A)</p>	*
Checksum	<p>2 bytes. The parameter indicates the sum of all data (excluding the checksum and ending mark). It is a hexadecimal character.</p> <p>Example: <code>\$\$<Data identifier><Data length><IMEI><Command type><Command>*Checksum>\r\n</code></p>	BE
\r\n	<p>2 bytes. The parameter is an ending character. The type is ASCII.</p> <p>(Hexadecimal value: 0x0d 0x0a)</p>	\r\n

1.3 Event Code

Event Code	Event	Default SMS Header (At Most 16 Bytes)
1	SOS Pressed	SOS
2	Input 2 Active	Ignition On: MVT100&MVT340 Door Open: MVT380
3	Input 3 Active	In3 Active
4	Input 4 Active	Ignition On: MVT380
5	Input 5 Active	In5 Active
9	Input 1 Inactive	In1 Inactive
10	Input 2 Inactive	Ignition Off: MVT100&MVT340 Door Close: MVT380
11	Input 3 Inactive	In3 Inactive
12	Input 4 Inactive	Ignition Off: MVT380
13	Input 5 Inactive	In5 Inactive
17	Low Battery	Low Battery
18	Low External Battery	Low Ext-Battery
19	Speeding	Speeding
20	Enter Geo-fence	Enter Fence N (N means the number of the fence)
21	Exit Geo-fence	Exit Fence N (N means the number of the fence)
22	External Battery On	Ext-Battery On
23	External Battery Cut	Ext-Battery Cut
24	GPS Signal Lost	GPS Signal Lost
25	GPS Signal Recovery	GPS Recovery
26	Enter Sleep	Enter Sleep
27	Exit Sleep	Exit Sleep
28	GPS Antenna Cut	GPS Antenna Cut
29	Device Reboot	Power On
31	Heartbeat	/
32	Cornering	Cornering
33	Track By Distance	Distance
34	Reply Current (Passive)	Now
35	Track By Time Interval	Interval
36	Tow	Tow
65	Press Input 1 (SOS) to Call	/
66	Press Input 2 to Call	/
67	Press Input 3 to Call	/
68	Press Input 4 to Call	/
69	Press Input 5 to Call	/
70	Reject Incoming Call	/
71	Get Location by Call	/
72	Auto Answer Incoming Call	/

73	Listen-in (Voice Monitoring)	/
----	-------------------------------------	---

2 Command List

Command	Command Description
A10	Real-Time Location Query
A11	Setting a Heartbeat Packet Reporting Interval
A12	Tracking by Time Interval
A13	Setting the Cornering Report Function
A14	Tracking by Distance
A15	Setting the Parking Scheduled Tracking Function
A16	Enabling the Parking Scheduled Tracking Function
A21	Setting GPRS Parameters
A22	Setting the DNS Server IP Address
A23	Setting the Standby GPRS Server
A70	Reading All Authorized Phone Numbers
A71	Setting Authorized Phone Numbers
A72	Setting Listen-in Phone Numbers
A73	Setting the Smart Sleep Mode
AAA	Automatic Event Report
AFF	Deleting a GPRS Event in the Buffer
B05	Setting a Geo-Fence
B06	Deleting a Geo-Fence
B07	Setting the Speeding Alarm Function
B08	Setting the Towing Alarm Function
B21	Setting the Anti-Theft Function
B31	Turning off the LED Indicator
B34	Setting a Log Interval
B35	Setting the SMS Time Zone
B36	Setting the GPRS Time Zone
B60	Checking the Engine First to Determine Tracker Running Status
B91	Setting SMS Event Characters
B99	Setting Event Authorization
C01	Output Control
C02	Notifying the Tracker of Sending an SMS
C03	Setting a GPRS Event Transmission Mode
E91	Reading Device's Firmware Version and SN
F01	Restarting the GSM Module
F02	Restarting the GPS Module
F08	Setting the Mileage and Run Time
F09	Deleting SMS/GPRS Cache Data
F11	Restoring Initial Settings

3 Command Details

3.1 Real-Time Location Query – A10

GPRS Sending	A10
GPRS Reply	AAA,34,(-)Latitude,(-)Longitude,Date and time,Positioning status,Number of satellites,GSM signal strength,Speed,Direction,HDOP,Altitude,Mileage,Run time,Base station info,I/O port status,Analog input value
Description	34: indicates the GPRS command event code.
Example	
GPRS Sending	@@Q25,353358017784062,A10*6A\r\n
GPRS Reply	\$\$Q128,353358017784062,AAA,34,22.543176,114.078448,100313093738,A,5,22,2,205,5,-14,0,60,0 0 10133 4110,0000,149 153 173 2707 914,*91\r\n

3.2 Setting a Heartbeat Packet Reporting Interval – A11

GPRS Sending	A11,Interval
GPRS Reply	A11,OK
Description	<p>The heartbeat packet function is used to keep the Transmission Control Protocol (TCP) connection open when the interval of scheduled GPRS reporting is long.</p> <p>Interval = 0: function disabled (default).</p> <p>Interval = [1...65535]: function enabled. Unit: minute.</p> <p>The heartbeat function is available only in conjunction with deep sleep mode. When the device enters deep sleep mode, heartbeat reports will be sent at the specified interval. A heartbeat report is to confirm the device is online, but positioning data is invalid.</p>
Example	
GPRS Sending	@@S28,353358017784062,A11,10*FD\r\n
GPRS Reply	<p>\$\$S28,353358017784062,A11,OK*FE\r\n</p> <p>After the above command is run successfully, the tracker will send the following GPRS heartbeat packet to the platform every 10 minutes in sleep mode:</p> <p>\$\$a131,353358017784062,AAA,31,22.913458,114.083183,080229123628,V,9,23,21,83,1,18,1350,127,0 0 10133 4110,0000,169 181 184 2714 919,*60</p>

3.3 Tracking by Time Interval – A12

GPRS Sending	A12,Interval
GPRS Reply	A12,OK
Description	<p>Unit: x10 seconds</p> <p>Interval = 0: function disabled.</p> <p>The maximum time interval is 65535 x 10 seconds.</p> <p>6 x 10 seconds are recommended.</p>
Example	
GPRS Sending	@@V27,353358017784062,A12,6*D5\r\n

GPRS Reply	<pre>\$\$V28,353358017784062,A12,OK*02\r\n</pre> <p>After the above command is run successfully, the tracker will send the following GPRS data packet to the platform every 1 minute:</p> <pre>\$\$W129,353358017784062,AAA,35,22.540113,114.076141,100313094354,A,5,22,1,174,4,129,0,435,0 0 10133 4110,0000,166 224 193 2704 916,*BE\r\n</pre>
------------	--

3.4 Setting the Cornering Report Function – A13

GPRS Sending	A13,Angle
GPRS Reply	A13,OK
Description	<p>When the driving angle exceeds the preset value, the tracker will send a GPRS data packet with location information to the server, which ensures a smoother route on the platform.</p> <p>Angle = 0: function disabled (default). Angle = [1...359]: function enabled. Recommended value: 30.</p>
Example	
GPRS Sending	@@X29,353358017784062,A13,120*37\r\n
GPRS Reply	<pre>\$\$X28,353358017784062,A13,OK*05\r\n</pre> <p>After the above command is run successfully, if the cornering angle is greater than 120 degree, the tracker will send the following GPRS data packet to the server:</p> <pre>\$\$Y129,353358017784062,AAA,32,22.540968,114.077455,100313094534,A,4,22,1,166,3,175,0,534,0 0 10133 4110,0000,141 138 159 2691 904,*D9\r\n</pre>

3.5 Tracking by Distance – A14

GPRS Sending	A14,Distance
GPRS Reply	A14,OK
Description	<p>Distance = 0: function disabled (default). Distance = [1...65535]: function enabled. Unit: meter.</p> <p>Note: When both the GPRS time interval and distance tracking functions are enabled, the "first reach first report" rule will be applied. For example, set the time interval to 6 x 10 seconds and distance to 200 meters. If the road is clear, a distance data packet will be reported first; if there is heavy traffic on the road, a time interval data packet will be reported first. Then both the time interval and distance counters will be reset to 0.</p> <p>300 is recommended.</p>
Example	
GPRS Sending	@@D30,353358017784062,A14,1000*4A\r\n
GPRS Reply	<pre>\$\$D28,353358017784062,A14,OK*F2\r\n</pre> <p>After the above command is run successfully, if the driving distance reaches 1000m, the tracker will send a data packet to the server.</p> <pre>\$\$D131,353358017784062,AAA,33,22.547271,114.047405,080310080929,A,8,21,13,89,1,12,8525,561,0 0 10133 4110,0000,163 185 186 2712 939,*31\r\n</pre>

3.6 Setting the Parking Scheduled Tracking Function – A15

GPRS Sending	A15, <i>Interval</i>
GPRS Reply	A15,OK
Description	<p>The function is available for vehicle trackers only. With the function, the number of GPRS messages is reduced, and thus GPRS traffic is saved.</p> <p>After the A15 function is set, the A16 function is automatically enabled. For details about engine status, see section 3.7 "Enabling the Parking Scheduled Tracking Function – A16."</p> <p>Interval unit: x10 seconds</p> <p>Interval = 0: function disabled.</p> <p>The maximum interval is 65535 x 10 seconds.</p> <p>Note: If data needs to be sent at the specified interval after the vehicle starts or stops, the function needs to work with the A12 function.</p>
Example	
GPRS Sending	@@E27,353358017784062,A15,6*C7\r\n
GPRS Reply	\$\$E28,353358017784062,A15,OK*F4\r\n

3.7 Enabling the Parking Scheduled Tracking Function – A16

GPRS Sending	A16, <i>Status</i>
GPRS Reply	A16,OK
Description	<p>The first positive input port (high level) of a vehicle tracker (MVT100/MVT340/MVT380) must connect to engine detection. Otherwise, the function is unavailable.</p> <p>When the activation status is 1, the parking scheduled tracking function is enabled. GPRS data is sent at the following interval:</p> <ul style="list-style-type: none"> ● Interval of the A12 function when the engine is on ● Interval of the A15 function when the engine is off <p>When the activation status is 0, the function is disabled. GPRS data is sent at the following interval:</p> <ul style="list-style-type: none"> ● Interval of the A12 function when the engine is on ● Interval of the A12 function when the engine is off
Example	
GPRS Sending	@@F27,353358017784062,A16,0*C3\r\n
GPRS Reply	\$\$F28,353358017784062,A16,OK*F6\r\n

3.8 Setting GPRS Parameters – A21

GPRS Sending	A21, <i>Connection mode,IP address,Port,APN,APN user name,APN password</i>
GPRS Reply	A21,OK
Description	<p>Connection mode = 0: function disabled.</p> <p>Connection mode = 1: function enabled; use TCP/IP reporting mode.</p>

	<p>Connection mode = 2: function enabled; use UDP reporting mode.</p> <p>IP address: IP address or domain name. A maximum of 32 bytes are supported.</p> <p>Port: a maximum of 5 digits.</p> <p>APN/APN user name/APN password: a maximum of 32 bytes respectively.</p> <p>If no user name and password are required, leave them blank.</p> <p>Note:</p> <ol style="list-style-type: none"> 1. If you want to change a parameter (named A), the parameter before A cannot be empty. 2. If you do not want to change the parameters after A, no comma is required when you edit the command. 3. If you want to clear the parameters after A, commas are required when you edit the command. <p>For example, if you want to change the IP address and port only, send A21,1,192.168.1.1,8800.</p>
Example	
GPRS Sending	@@H48,353358017784062,A21,1,67.203.13.26,8800,,,*C9
GPRS Reply	\$\$H28,353358017784062,A21,OK*F4\r\n

3.9 Setting the DNS Server IP Address – A22

GPRS Sending	A22,DNS server IP address
GPRS Reply	A22,OK
Description	<p>An incorrect DNS server IP address may lead to GPRS data reporting failures after the A21 command is used. Use the A22 command to set the DNS server IP address (confirm the IP address with your domain name provider.). Then use the A21 command to reset the domain name.</p> <p>DNS server IP address: a maximum of 16 bytes</p>
Example	
GPRS Sending	@@K38,353358017784062,A22,75.127.67.90*FD\r\n
GPRS Reply	\$\$K28,353358017784062,A22,OK*F8\r\n

3.10 Setting the Standby GPRS Server – A23

GPRS Sending	A23,IP address,Port
GPRS Reply	A23,OK
Description	<p>IP address: a maximum of 32 bytes</p> <p>Port: a maximum of 5 digits</p> <p>When the tracker fails to send data to the active server set by command A21, data is automatically sent to the standby server to prevent data loss.</p>
Example	
GPRS Sending	@@S43,353358017784062,A23,67.203.13.26,8800*F0
GPRS Reply	\$\$S28,353358017784062,A23,OK*01\r\n

3.11 Reading All Authorized Phone Numbers – A70

GPRS Sending	A70
GPRS Reply	A70,SOS phone number 1,SOS phone number 2,SOS phone number 3,Listen-in phone number 1,Listen-in phone number 2
Description	Read all authorized phone numbers.
Example	
GPRS Sending	@@T25,353358017784062,A70*93\r\n
GPRS Reply	\$\$T85,353358017784062,A70,13811111111,13822222222,13833333333,13844444444,13855555555*21\r\n

3.12 Setting Authorized Phone Numbers – A71

GPRS Sending	A71,Phone number 1,Phone number 2,Phone number 3
GPRS Reply	A71,OK
Description	<p>Phone number: A phone number has a maximum of 16 bytes. If no phone numbers are set, leave them blank. Phone numbers are empty by default.</p> <p>Phone number 1: SOS phone number. When you call the tracker by using the phone number, you will receive SMS notification about the location, geo-fence alarm and low power alarm.</p> <p>When the SOS button is pressed, the tracker will dial phone numbers 1, 2, and 3 in sequence. The tracker stops dialing when a phone number responds.</p>
Example	
GPRS Sending	@@U61,353358017784062,A71,13811111111,13822222222,13833333333*7D\r\n
GPRS Reply	\$\$U28,353358017784062,A71,OK*06\r\n

3.13 Setting Listen-in Phone Numbers – A72

GPRS Sending	A72,Listen-in phone number 1,Listen-in phone number 2
GPRS Reply	A72,OK
Description	<p>When you call the tracker by using authorized listen-in phone numbers, the tracker will answer the call automatically and enter the listen-in state. In this way, the tracker will not make any sound.</p> <p>A maximum of two phone numbers can be set. Each phone number has a maximum of 16 digits. If no phone numbers are set, leave them blank. Phone numbers are empty by default.</p> <p>If no phone numbers are set and commas are remained, phone numbers set before will be deleted.</p>
Applicable Model	MVT380
Example	
GPRS Sending	@@V49,353358017784062,A72,13844444444,13855555555*55\r\n
GPRS Reply	\$\$V28,353358017784062,A72,OK*08\r\n

3.14 Setting the Smart Sleep Mode – A73

GPRS Sending	<i>A73,Sleep level</i>
GPRS Reply	<i>A73,OK</i>
Description	<p>Set the automatic smart sleep mode when the tracker is idle.</p> <p>Sleep level = 0: function disabled (default).</p> <p>Sleep level = 1: normal sleep. The GSM module always works, and the GPS module occasionally enters the sleep mode. The tracker works 25% longer in the normal sleep mode than that in the normal working mode. This mode is not recommended for short interval tracking; this will affect the route precision.</p> <p>Sleep level = 2: deep sleep. If no event is triggered after five minutes, the GPS module will stop working and the GSM module will enter sleep mode. Once an event is triggered, the GPS and GSM modules will be woken up. A heartbeat event will be triggered only in the deep sleep mode, which will be uploaded every one hour by default.</p> <p>Triggering events include: SOS alarm, low internal/external battery, external power status, GPS antenna cutoff alarm, towing alarm, high temperature, low temperature, fuel theft, vehicle theft, ACC ON, (button) changes on any input port, vibration, incoming call, SMS receiving, call, and heartbeat event (The GPS is disabled during heartbeat wakeup.).</p>
Example	
GPRS Sending	<i>@@W27,353358017784062,A73,2*D9\r\n</i>
GPRS Reply	<i>\$\$W28,353358017784062,A73,OK*0A\r\n</i>

3.15 Automatic Event Report – AAA

GPRS Event Report	<i>AAA,Command type,(-)Latitude,(-)Longitude,Date and time,Positioning status,Number of satellites,GSM signal strength,Speed,Direction,HDOP,Altitude,Mileage,Run time,Base station info,I/O port status,Analog input value</i>
Description	When an event occurs, the tracker automatically reports the event to the server.
Example	
GPRS Reply	<p>When you press the SOS button, the tracker will send the following information to the server:</p> <p><i>\$\$G127,353358017784062,AAA,1,22.538169,114.075958,100313095653,A,3,21,4,46,5,581,0,148,0 0 10133 4172,0000,166 204 205 2709 878,*77\r\n</i></p>

3.16 Deleting a GPRS Event in the Buffer – AFF

GPRS Sending	<i>AFF,Number of deleted GPRS events</i>
GPRS Reply	<p>Use the AFF command to clear the existing data when the GPRS connection mode is UDP.</p> <p><i>AFF,Number of remaining cache,Command type, (-)Latitude,(-)Longitude,Data and time,Positioning status,Number of satellites,GSM signal</i></p>

	<i>strength,Speed,Direction,HDOP,Altitude,Mileage,Run time,Base station info,I/O port status,Analog input value</i>
Description	Number of deleted GPRS events: hexadecimal. In general, the number is 1. Number of remaining cache: indicates the number of events in the buffer; hexadecimal.
Example	
GPRS Sending	@@h27,353358017784062,AFF,1*0B\r\n
GPRS Reply	\$\$h28,353358017784062,AFF,OK*3D\r\n

3.17 Setting a Geo-Fence – B05

GPRS Sending	B05, <i>Geo-fence number,Latitude,Longitude,Radius,IN Geo-fence alarm,OUT Geo-fence alarm</i>
GPRS Reply	B05,OK
Description	Geo-fence number: 1–8. A maximum of eight geo-fences can be set. Latitude: latitude of the geo-fence center; decimal; accurate to 6 digits after the decimal point. If there are only 4 digits after the decimal point, add two digits 0. Otherwise, the command cannot be used successfully. Longitude: longitude of the geo-fence center; decimal; accurate to 6 digits after the decimal point. If there are only 4 digits after the decimal point, add two digits 0. Otherwise, the command cannot be used successfully. Radius: The value ranges from 1 to 4294967295. The unit is meter. IN Geo-fence alarm = 0: function disabled. IN Geo-fence alarm = 1: function enabled. OUT Geo-fence alarm = 0: function disabled. OUT Geo-fence alarm = 1: function enabled.
Example	
GPRS Sending	@@H57,353358017784062,B05,1,22.913191,114.079882,1000,0,1*96\r\n
GPRS Reply	\$\$H28,353358017784062,B05,OK*F7\r\n <i>When the tracker exits the geo-fence (latitude: 22.913191; longitude: 114.079882; radius: 1000m), it will send the following GPRS data packet to the server:</i> \$\$J132,353358017784062,AAA,21,22.918046,114.089726,080229123812,A,10,22,12,32,1,21,6667,847,0 0 10133 4110,0000,124 181 183 2714 922,*5A\r\n

3.18 Deleting a Geo-Fence – B06

GPRS Sending	B06, <i>Geo-fence number</i>
GPRS Reply	B06,OK
Description	Geo-fence number: 1–8. Only one geo-fence can be deleted each time by SMS or GPRS command.
Example	
GPRS Sending	@@J27,353358017784062,B06,1*C8\r\n
GPRS Reply	\$\$J28,353358017784062,B06,OK*FA\r\n <i>After the above command is run successfully, the first geo-fence will be deleted.</i>

3.19 Setting the Speeding Alarm Function – B07

GPRS Sending	B07,Driving speed
GPRS Reply	B07,OK
Description	Driving speed = 0: function disabled (default). Driving speed = [1...255]: function enabled. Unit: km/h. When the driving speed reaches the preset value, a speeding alarm will be generated.
Example	
GPRS Sending	@@P28,353358017784062,B07,60*05\r\n
GPRS Reply	\$\$P28,353358017784062,B07,OK*01\r\n When the tracker driving speed reaches 60 km/h, it will send the following information to the server: \$\$k134,353358017784062,AAA,19,22.916675,114.088813,080229123718,A,10,22,61,31,1,21,6635,395,460 0 10133 4110,0000,164 185 181 2712 915,*F7\r\n

3.20 Setting the Towing Alarm Function – B08

GPRS Sending	B08,Vibration duration
GPRS Reply	B08,OK
Description	When the tracker's vibration duration exceeds the preset value, the tracker will send an alarm to an authorized phone number or the server. Before using the towing alarm function, use the A73 command to set the smart sleep level to 2 and use the B08 command to set the consecutive vibration duration. Otherwise, the towing alarm function is unavailable. Vibration duration = 0: function disabled (default). Vibration duration = [1...255]: function enabled. Unit: second.
Example	
GPRS Sending	@@I27,353358017784062,B08,3*CB\r\n
GPRS Reply	\$\$I28,353358017784062,B08,OK*FB\r\n When the tracker vibrates for more than consecutive 3 seconds, it will send the following information to the server: \$\$K133,353358017784062,AAA,36,22.916675,114.088813,080229123718,A,10,22,61,31,1,21,6635,395,460 0 1013 4110,0000,164 185 181 2712 915,*A2

3.21 Setting the Anti-Theft Function – B21

GPRS Sending	B21,Status
GPRS Reply	B21,OK
Description	Status = 1: function enabled (default). An alarm is generated when the first negative input and first positive input of vehicle trackers excluding SOS are activated. Status = 0: function disabled. No alarm is generated when the first negative input and first positive input of vehicle trackers excluding SOS are activated.

	The following lists inputs of trackers:												
	<table border="1"> <thead> <tr> <th>Tracker</th> <th>Negative Input</th> <th>Positive Input</th> </tr> </thead> <tbody> <tr> <td>MVT100</td> <td>-</td> <td>Input 2</td> </tr> <tr> <td>MVT340</td> <td>-</td> <td>Input 2</td> </tr> <tr> <td>MVT380</td> <td>Input 2</td> <td>Input 4</td> </tr> </tbody> </table>	Tracker	Negative Input	Positive Input	MVT100	-	Input 2	MVT340	-	Input 2	MVT380	Input 2	Input 4
Tracker	Negative Input	Positive Input											
MVT100	-	Input 2											
MVT340	-	Input 2											
MVT380	Input 2	Input 4											
Example													
GPRS Sending	@@C27,353358017784062,B21,1*BE\r\n												
GPRS Reply	\$\$C28,353358017784062,B21,OK*F0\r\n												

3.22 Turning off the LED Indicator – B31

GPRS Sending	B31,A
GPRS Reply	B31,OK
Description	When A is 00 , the tracker's indicator is turned on (default). You can query the device's running status according to the indicator status. When A is 10 , the tracker's indicator is turned off.
Example	
GPRS Sending	@@J28,353358017784062,B31,10*F7\r\n
GPRS Reply	\$\$J28,353358017784062,B31,OK*F8\r\n

3.23 Setting a Log Interval – B34

GPRS Sending	B34, <i>Log interval</i>
GPRS Reply	B34,OK
Description	Set the interval for recording data to device's memory when the GPS signal is valid. Recorded logs can only be read by GPSLog or Meitrack Manager software. Log interval = 0: function disabled (default). Log interval = [1...65535]: function enabled. Unit: second.
Applicable Model	MVT100/MVT380
Example	
GPRS Sending	@@N28,353358017784062,B34,60*03\r\n
GPRS Reply	\$\$N28,353358017784062,B34,OK*FF\r\n

3.24 Setting the SMS Time Zone – B35

GPRS Sending	B35, <i>SMS minute</i>
GPRS Reply	B35,OK
Description	The default time zone of the tracker is GMT 0. You can run the B35 command to change the SMS report time zone to the local time zone. The SMS report time zone is different from the GPRS data packet time zone. When SMS minute is 0 , the time zone is GMT 0 . When SMS minute is a value ranging from -32768 to 32767, set time zones.

Example	
GPRS Sending	@@O29,353358017784062,B35,480*3C\r\n
GPRS Reply	\$\$O28,353358017784062,B35,OK*01\r\n <i>After the above command is run successfully, the tracker SMS time zone is changed to UTC+08:00 (China time zone).</i>

3.25 Setting the GPRS Time Zone – B36

GPRS Sending	B36,GPRS minute
GPRS Reply	B36,OK
Description	When GPRS minute is 0 , the time zone is GMT 0 (default). The MS02 can automatically detect the user time zone, so that the GPRS time zone does not need to be changed. Otherwise, inaccurate data occurs. When GPRS minute is a value ranging from -32768 to 32767, set time zones.
Example	
GPRS Sending	@@P29,353358017784062,B36,480*3E\r\n
GPRS Reply	\$\$P28,353358017784062,B36,OK*03\r\n <i>After the above command is run successfully, the GPRS time zone is changed to UTC+08:00 (China time zone).</i>

3.26 Checking the Engine First to Determine Tracker Running Status – B60

GPRS Sending	B60,X
GPRS Reply	B60,OK
Description	X = 0: function disabled (default). X = 1: function enabled. When the device detects ACC OFF, device's longitude and latitude will not be updated, so as to avoid static drift. The first positive input of the tracker connects to engine detection by default.
Example	
GPRS Sending	@@U27,353358017784062,B60,1*D3\r\n
GPRS Reply	\$\$U28,353358017784062,B60,OK*05\r\n

3.27 Setting SMS Event Characters – B91

GPRS Sending	B91,SMS event code,SMS header
GPRS Reply	B91,OK
Description	Header: a maximum of 16 bytes
Example	
GPRS Sending	@@R31,353358017784062,B91,1,SOS*F0\r\n
GPRS Reply	\$\$R28,353358017784062,B91,OK*06\r\n <i>After you press the SOS button (input 1), the tracker will send an alarm SMS whose header is SOS to a preset authorized phone number.</i>

3.28 Setting Event Authorization – B99

GPRS Sending	<p>B99,<SMS>/<0>,<Phone number location>/<Authorized phone number>,<Operation code>, [Event code 1].....[Event code n]</p> <p>B99,<CALL>/<1>,<Phone number location>/<Authorized phone number>,<Operation code>, [Event code 1].....[Event code n]</p> <p>B99,<GPRS>/<2>,<Operation code>, [Event code 1].....[Event code n]</p> <p>B99,<CAMERA>/<3>,<Operation code>, [Event code 1].....[Event code n]</p> <p>B99,<BUZZER>/<4>,<Operation code>, [Event code 1].....[Event code n].</p>
GPRS Reply	<p>B99,<SMS>/<0>,<Phone number location>,<Authorized phone number>, [Event code 1].....[Event code n]</p> <p>B99,<CALL>/<1>,<Phone number location>,<Authorized phone number>, [Event code 1].....[Event code n]</p> <p>B99,<GPRS>/<2>,[Event code 1].....[Event code n]</p> <p>B99,<CAMERA>/<3>,[Event code 1].....[Event code n]</p> <p>B99,<BUZZER>/<4>,[Event code 1].....[Event code n]</p>
Description	<p>Fields SMS, CALL, CAMERA, GPRS, and BUZZER can be presented by 0–4 in decimal string.</p> <p>Operation codes GET, SET, ADD, and DEL can be presented by 0–3 in decimal string. These characters are not case-sensitive.</p> <p>Note: Ensure that an authorized phone number is set by using the A71 command or the parameter configuration tool before the B99 command is used to set the SMS/CALL event code. The tracker compares the authorized phone number issued by B99 with the authorized phone number (excluding +86 characters) of the tracker. If the phone numbers are the same, the new event code will be stored. If the phone numbers are inconsistent, an error SMS will be sent.</p>

Example

GPRS Sending	@@B34,863070010825791,B99,gprs,get*BC\r\n
GPRS Reply	\$\$B33,863070010825791,B99,1,17,18*B5\r\n

3.29 Controlling Output Status – C01

GPRS Sending	C01,Speed,ABCDE
GPRS Reply	C01,OK
Description	<p>When the speed is 0, no speed limit exists. That is, when the tracker receives a command, the output control takes effect immediately.</p> <p>When the speed is a value ranging from 1 to 255 (unit: km/h), set the speed limit for output control. When the driving speed is lower than the speed limit, the output control takes effect.</p> <p>A=0, close output (OUT1) - open drain</p> <p>A=1, open output (OUT1) - connect to GND</p> <p>A=2, remain previous status.</p> <p>B=0, close output (OUT2) - open drain</p>

	<p>B=1, open output (OUT2) - connect to GND</p> <p>B=2, remain previous status.</p> <p>C=0, close output (OUT3) - open drain</p> <p>C=1, open output (OUT3) - connect to GND</p> <p>C=2, remain previous status.</p> <p>D=0, close output (OUT4) - open drain</p> <p>D=1, open output (OUT4) - connect to GND</p> <p>D=2, remain previous status.</p> <p>E=0, close output (OUT5) - open drain</p> <p>E=1, open output (OUT5) - connect to GND</p> <p>E=2, remain previous status.</p>
Example	
GPRS Sending	@@M34,353358017784062,C01,20,10122*18\r\n
GPRS Reply	\$\$M28,353358017784062,C01,OK*F9\r\n

3.30 Notifying the Tracker of Sending an SMS – C02

GPRS Sending	C02, X, <i>Phone number,Content</i>
GPRS Reply	C02,OK
Description	<p>Used for the platform to notify the tracker of sending an SMS to a mobile phone.</p> <p>X = 0: in TEXT mode</p> <p>X = 1: in Unicode mode</p> <p>Phone number: a maximum of 16 digits</p> <p>Content: a maximum of 140 characters</p> <p>After receiving the message, the tracker sends Content information to specified phone numbers.</p>
Example	
GPRS Sending	@@f47,353358017784062,C02,0,15360853789,Meitrack*B1\r\n
GPRS Reply	\$\$f28,353358017784062,C02,OK*13\r\n

3.31 Setting a GPRS Event Transmission Mode – C03

GPRS Sending	C03, X
GPRS Reply	C03,OK
Description	<p>X = 0: automatic event report (default)</p> <p>X = 1: Before another event can be transmitted, existing event reports need to be confirmed and deleted on the server by the AFF command. Select this mode when GPRS uses UDP.</p>
Example	
GPRS Sending	@@f27,353358017784062,C03,0*E1\r\n
GPRS Reply	\$\$f28,353358017784062,C03,OK*14\r\n

3.32 Reading Device's Firmware Version and SN – E91

GPRS Sending	E91
GPRS Reply	E91,Version,SN
Description	Read the tracker's firmware version and SN.
Example	
GPRS Sending	@@W25,353358017784062,E91*7D\r\n
GPRS Reply	\$\$W38,353358017784062,FWV1.00,12345678*1C\r\n

3.33 Restarting the GSM Module – F01

GPRS Sending	F01
GPRS Reply	F01,OK
Description	Restart the GSM module.
Example	
GPRS Sending	@@j25,353358017784062,F01*88\r\n
GPRS Reply	\$\$j28,353358017784062,F01,OK*19\r\n

3.34 Restarting the GPS Module – F02

GPRS Sending	F02
GPRS Reply	F02,OK
Description	Restart the GPS module.
Example	
GPRS Sending	@@Z25,353358017784062,F02*79\r\n
GPRS Reply	\$\$Z28,353358017784062,F02,OK*0A\r\n

3.35 Setting the Mileage and Run Time – F08

GPRS Sending	F08,Run time,Mileage
GPRS Reply	F08,OK
Description	<p>Run time:</p> <ul style="list-style-type: none"> ● Value range: [0...4294967295] ● Decimal ● Unit: second <p>If you do not want to set the parameter, leave it blank.</p> <p>Mileage:</p> <ul style="list-style-type: none"> ● Value range: [0...4294967295] ● Decimal ● Unit: meter <p>If you do not want to set the parameter, leave it blank.</p>
Example	

GPRS Sending	@@D40,353358017784062,F08,0,4825000*51\r\n
GPRS Reply	\$\$D28,353358017784062,F08,OK*FA\r\n

3.36 Deleting SMS/GPRS Cache Data – F09

GPRS Sending	F09,Number
GPRS Reply	F09,OK
Description	If the number is 1 , SMS cache data to be sent is deleted. If the number is 2 , GPRS cache data to be sent is deleted. If the number is 3 , SMS and GPRS cache data to be sent is deleted.
Example	
GPRS Sending	@@E27,353358017784062,F09,1*CA\r\n
GPRS Reply	\$\$E28,353358017784062,F09,OK*FC\r\n

3.37 Restoring Initial Settings – F11

GPRS Sending	F11
GPRS Reply	F11,OK
Description	Restore initial settings except the SMS password.
Example	
GPRS Sending	@@[25,353358017784062,F11*7A\r\n
GPRS Reply	\$\$[28,353358017784062,F11,OK*0B\r\n

If you have any questions, do not hesitate to email us at info@meitrack.com.